

 <b>WHITE GOODS</b>	<b>REFRIGERATOR</b>	<b>CUSTOMER SUPPORT</b>
	<b>ASSEMBLE &amp; DISASSEMBLE</b>	

### Changing The Door Swing Direction to Right Hand

1- Unscrew the two screws fixing the top hinge (Fig-1) and bottom hinge. (Fig-2)  
Remove the door. (Fig-1)



**Figure 1**



**Figure 2**

2- Remove the top hinge screw caps (big) on the left side (Fig-3) and insert them to the right side. (Fig-4)



**Figure 3**



**Figure 4**

3- Remove the bottom hinge screw caps (big) on the left side and insert them to the right side. (Fig-5)



**Figure 5**

 <b>WHITE GOODS</b>	<b>REFRIGERATOR</b>	<b>CUSTOMER SUPPORT</b>
	<b>ASSEMBLE &amp; DISASSEMBLE</b>	

4- Assemble the top hinge to the bottom of the door (Fig-6) and assemble the door and then assemble the bottom hinge to the top of the door. (Fig-7)




**Figure 6**



**Figure 7**

 <b>WHITE GOODS</b>	<b>REFRIGERATOR</b>	<b>CUSTOMER SUPPORT</b>
	<b>THERMOSTAT SETTING</b>	



- Thermostat automatically regulates the inside temperature of the refrigerator compartment and freezer compartment. By rotating the knob from position 1 to 5, colder temperatures can be obtained.
- The “ 0 “ position shows thermostat is closed and no cooling is available.
- For short-term storage of food in the freezer compartment, you can set the knob between minimum and medium position (1-3).
- For long-term storage of food in the freezer compartment, you can set knob medium position.(3-4)
- **Note that; the ambient temperature, temperature of the freshly stored food and how often the door is opened, affects the temperature in the refrigerator and freezer compartments. If required, change the temperature setting.**
- *When you first switch on the appliance, you should ideally try to run it without any food in for 24 hours and not open the door. If you need to use it straight away, try not to put much food inside.*
- *If the unit is switched off or unplugged, you must allow at least 5 minutes before restarting in order not to damage the compressor.*